



MODEL PC196 PARTS LIST

| ITEM # | QTY | DESCRIPTION |
|--------|-----|---------------------------|
| 100 | 1 | CASING |
| 101 | 1 | IMPELLER |
| 105 | 1 | RING, LANTERN |
| 106 | 5 | PACKING |
| 107 | 1 | GLAND, PACKING |
| 108 | 1 | ADAPTER |
| 112 | 1 | BEARING, OUTBOARD |
| 113 | 1 | PLUG, OIL FILL |
| 122 | 1 | SHAFT |
| 126 | 1 | SLEEVE, SHAFT |
| 134 | 1 | HOUSING, BEARING |
| 136 | 1 | LOCKNUT, BEARING |
| 168 | 1 | BEARING, INBOARD |
| 184 | 1 | COVER, STUFFING BOX |
| 228 | 1 | BEARING FRAME |
| 241 | 1 | BEARING FRAME FOOT |
| 250 | 1 | GLAND, MECHANICAL SEAL |
| 310 | 1 | GAUGE: SIGHT, OIL |
| 332A | 1 | LARYRINTH, OUTBOARD FRAME |
| 333A | 1 | LARYRINTH, INBOARD FRAME |
| 351 | 1 | GASKET, CASE |
| 353 | 4 | STUD, GLAND |
| 353A | 4* | NUT, GLAND STUD |
| 358A | 1 | PLUG, CASING DRAIN |

| ITEM # | QTY | DESCRIPTION |
|--------|-----------|-----------------------------------|
| 360D | 1 | GASKET, FRAME/ADAPTER |
| 360Q | 1 | GASKET GLAND, MECH. SEAL |
| 361A | 1 | SNAP RING, BEARING |
| 370 | 0, 12, 15 | BOLT, CASING |
| 370B | 4 | BOLT, FRAME/ADAPTER |
| 370C | 3 | BOLT, FRAME/BEARING HOUSING |
| 370D | 3 | JACK BOLT, BEARING HOUSING |
| 370F | 2 | BOLT FRAME FOOT |
| 370H | 2 | BOX COVER/ADAPTER STUD |
| 382 | 1 | LOCKWASHER, BEARING |
| 383 | 1 | SEAL, MECH. ROTATING ELEMENT |
| 385 | 1 | SEAL, MECH. STATIONERY ELEMENT |
| 400 | 1 | KEY, COUPLING |
| 408A | 1 | PLUG, FRAME DRAIN |
| 412 | 1 | O-RING, IMPELLER |
| 423 | 3 | JAMNUT, BEARING HOUSING JACK BOLT |
| 460B | 2 | DOWEL PIN, FRAME/ADAPTER |
| 496 | 1 | O-RING, BEARING HOUSING/FRAME |
| 529 | 2 | WASHER, FRAME FOOT TO FOOT |

*PACKING GLAND HAS ONLY 2 STUDS & NUTS

* Accurate for MTE, LTE, XLTE frames.
The STE frame has the adapter and bearing housing foot integral with the bearing frame.



Manufacturers of pumps & pump parts since 1980

P.O. Box 7551, Savannah, Georgia 31418 • Tele: (912) 233-PUMP (233-7867) • Fax: (912) 232-8538
Email: sales@pumpcomponents.com • Website: pumpcomponents.com